



Zhuozhou Ding Song Trade Co., Ltd.

Digital Display
COMPRESSION
Testing Machine

DYE -2000





Digital Display Hydraulic Compression Testing Machine

- Model: DYE - 2000
- Display:: Digital
- Brand : SF
- Manufacturing Country : China
- Country Of origin : China

Product introduction: The testing machine is mainly used to measure the compressive strength of brick, stone, concrete and other building materials. It is a necessary test and detection equipment for construction, building materials, highway bridges and other engineering units. This machine is electric hydraulic manual loading, sensor force measurement. It has the functions of loading speed display, peak value maintenance, data storage, printing, query and compressive strength conversion.





Hydraulic system:

The hydraulic oil in the oil tank enter the oil circuit through the motor drives the high-pressure pump, flows through the return oil valve, and into the oil cylinder. The force measuring instrument collects and analyzes the data through the sensor, showing the constant force value. The operator through the delivery valve to adjust the flow and control the test force rate.

System of force measurement:

- Manually adjust the return valve; the operation is simple and flexible.
- Has the maximum load peak maintain function.
- Has loading rate dynamic display function.
- Has a random test report with test date, number, damage load, compression strength etc.

■ Safety protection

When the test force exceeds 3% of the maximum test force, overload protection will be implemented and the oil pump motor will stop.





■ **Main technical specification:**

Max Load	2000kN
-----------------	---------------

Host structure		Four-column structure
Measuring range		10% - 99%
Relative error of test force indicating value		Within $\pm 1\%$
Upper Press Plate size		Ø 250
The Maximum oil pressure		40 Mpa
Lower Press Plate size		Ø 260
Stander		ASTM C-109, ASTM T106
Test Machine Precision Level		1 (level)
Distance between up and down pressure plates		360 mm
Platen size	Upper: $\phi 250\text{mm}$ Lower : 220 x 220mm	
Piston stroke		0-50 mm
Piston action direction control		one-way cylinder
Power supply		220V, 50Hz
Motor power		1.2 kW
Shape Size		900mm x 360mm x 1250mm
Package dimensions (About)		1100 x 560x 1380mm
Weight		About 650kg



■ Factory standard configuration list

Item	Quantity	Notes
Testing machine	1 set	With motor, oil pump, return valve
Force measuring	1 set	On the mainframe and instrument
Including a Micro Printer.		
Pressure sensor		1 piece
Up and down pressure plates		1 piece
Instruction/certificate/packing list.		1 set

■ Working Environment Conditions of Testing Machine

- ✓ Ambient temperature range:10°C–35°C, if have special requirements,
- ✓ The test temperature should be 23°C±5°C.
- ✓ Placed on a solid foundation.
- ✓ In a clean environment with no vibration.
- ✓ No strong electromagnetic interference surrounding.
- ✓ Power supply voltage fluctuation range should be not more than plus or minus 10%



Rahim Trading Corporation –RTC 'Supply, Testing & Commissioning of Compression Testy machine (CTM) for cylinder, brick, block, Automatic etc.

This Machine 2000KN Microcomputer Control Electro-Hydraulic Servo

Compression Testing Machine (CTM) Technical specification:

- ✓ Capacity:2000KN
- ✓ CompressionPlateSize:510x 320mm
- ✓ Max.Vertical Clearance Between Platen: 380mm
- ✓ Suitable for Compressive strength test of Brick,
- ✓ Block size 390mmX190mmX190mm
- ✓ Cube, Cylinder Size :150mm X 300mm & 100mm X 200mm





Importer and Supplier in Bangladesh.

**SOURCE
QUALITY
PRODUCTS
RTC DHAKA**



01831-016720



www.rtc dhaka.com

+88 01831-016720

rtcdhaka2013@gmail.com

02226-639513

www.rtc dhaka.com

Swantex Bhaban (2nd Floor) South Side, 9/I, Motijheel C/A Dhaka-1000, Bangladesh.