

Cone Marsh Funnel Measuring Cup

Viscosity Test marsh cone viscometer

Number	Technical	Technical indicators
1	Mesh size	1.6mm 12mesh
2	Funnel volume	1500ml
3	Accuracy	When pouring 1500ml of standard distilled water into funnel, the time for pouring out 946ml of the water is $26 \pm 0.5s$.
4	Product	Marsh funnel

- Marsh funnel is an apparatus used to measure the viscosity of drilling fluids for daily. Adopting the API standard, determine the viscosity of drilling fluids with the time required for a given volume of drilling fluids pouring out from the funnel. The structure of the apparatus is simple. It is convenient for use and applied extensively in the departments dealing with petroleum and geological exploration.
- Model MLN Hot sell API standard marsh funnel viscometer for drilling fluid
- Usage of Marsh Funnel Viscometer Marsh Funnel Viscometer, field tool used to measure the viscosity of drilling mud. Stainless steel 12-mesh screen covers half of the top and is designed to remove any foreign matter and drilled cuttings from the fluid. The fluid runs through a fixed orifice at the end of the funnel – 2" (50.8mm) x 3/16" (4.7mm).





CERTIFICATE

ATTESTATION CERTIFICATE OF MACHINERY AND ELECTROMAGNETIC COMPATIBILITY DIRECTIVES

Technical file of the company mentioned below has been observed

2006/42/EC Machinery Directive and 2014/30/EU Electromagnetic Compatibility Directive
have been taken as references for these processes

Company Name : Cangzhou Oubeirulke Instrument And Equipment Co., Ltd.

Company Address : Nanguan Village, Leshouzhen, Xian County, Cangzhou City,
Hebei Province, China

Related Directives and Annex : 2006/42/EC Machinery Directive
2014/30/EU Electromagnetic Compatibility Directive

Related Standards : EN ISO 12100:2010, EN 60204-1:2018, EN 61000-6-2:2019
EN 61000-6-4:2019, EN 61000-3-2:2019+A1:2021
EN 61000-3-3:2013+A1:2019, EN 12697-22:2020

Product Name : Asphalt Mixture Testing Machine

Report No and Date : XMT0202101397S/MD, XMT0202101398S/EMC

Product Brand/Model/Type : LHCZ-6, LHCX-1, BH-10, BH-20, MDJ-III A, MDJ-III C, LWD-III A,
LWD-III C, CT-3000, HYRS-6

Certificate Number : M.2021.206.C70241

Initial Assessment Date : 28.12.2021

Registration Date : 29.12.2021

Reissue Date/No : -

Expiry Date : 28.12.2026


UDEM International Certification
Auditing Training Centre Industry
and Trade Inc.Co.

The validity of the certificate can be checked through www.udemltd.com.tr. The CE mark shown on the right can only be used under the responsibility of the manufacturer with the completion of EC Declaration of Conformity for all the relevant Directives. This certificate remains the property of UDEM International Certification Auditing Training Centre Industry and Trade Co. Ltd. to whom it must be returned upon request. The above named firm must keep a copy of this certificate for 15 years from the registration of certificate. This certificate only covers the product(s) stated above and UDEM must be noticed in case of any changes on the product(s)

Address: Mutlukent Mahallesi 2073 Sokak (Eski 93 Sokak) No:10 Çankaya - Ankara - TURKEY

Phone: +90 0312 443 03 90 Fax: +90 0312 443 03 76

E-mail: info@udemltd.com.tr www.udem.com.tr

